SPL8M.CTR Chrome Voice Coil Trim Ring Upgrade For 8" SPL Midranges





Instruction manual

Installing the trim ring is straightforward. Start by inserting a piece of paper down, around the phase plug to ensure no adhesive makes contact with the pole piece. Ensure the surfaces are clean and dry and apply a small amount of flexible adhesive to the trim ring. Using a pair of tweezers carefully position the trim ring down over the protruding part of the voice coil, and apply gentle pressure using a finger around it. The trim will seat neatly onto the VC top. We do not recommend the use of superglue for this operation. Wurth Zebra, Gorilla Glue or any other thick silicone or flexible adhesive seems to work the best.

