

**Team RED15/1 15" 38cm 2x10hm DVC
Wide Excursion Competition Subwoofer
3500W RMS (Ported Enclosures)**

Team



Instruction manual

Thank you for choosing Bassface. From the simplest connector to our top of the range amplifier - every element of these products has been designed to give you the best possible performance for your money. Please take the time to read these instructions carefully as they contain useful and important information. Modern high power audio systems can generate voltages at the speaker similar to mains operated equipment - for some reason everyone seems to ignore or forget this. Your wiring needs to be good to be safe. Please remember this and take your time. Please exercise caution when setting volume levels - powerful audio equipment can easily produce enough sound to permanently damage hearing. Remember that audio competitors use ear protection when operating and competing. Do remember that incorrect installation or abuse is not covered under warranty - please make sure that your installation and any partnered product is suitable and compatible. If you are unsure please seek qualified advice before proceeding. Always use appropriate hand and eye protection when working with tools, and always work within your capabilities as an installer. We offer a 12 month manufacturer warranty via your distributor or retailer. Please retain your purchase receipt as proof of purchase. Please note that Bassface operates a policy of continuous product development and we reserve the right to change specification without prior notice. You can follow our process on our website by reviewing the version history information.

Please note that we sometimes include information inside these manuals which we feel is of potential value to the client on related subjects such as conversion charts, capacitance values or wiring diagrams. Please feel free to copy any of this information since it is in the public domain.



Before tackling the installation of the speaker, it is CRITICALLY important to follow at least a basic break in procedure for the speaker. This operation will loosen up the moving components of the speaker which will prepare it for heavy use. Failure to run a proper break in can be responsible for failures such as ripped spiders, surrounds or tinsel leads. We advise to feed the speaker with a range of tones from a clean power source at gradually increasing amplitudes. Before you start, gently press on the cone - you will feel that it is very stiff, and not compliant. You can imagine the forces at play if you try to run that speaker like that in anger before break in. Start off by using the approximate resonant frequency of the speaker (the FS), and run the speaker on the bench. Observe the speaker carefully as you run the process - remember that the speaker will not have any power handling as it is not in a box or baffle plate. Just run it up so that the spider, surround and leads gradually get exercised. Don't overdrive the speaker - you DO NOT want to hear ANY bad noises from it during this process. It's gentle exercise to loosen it up. Once you have run the speaker for, say, an hour, recheck by switching everything off and pressing the cone. You will feel that it is much softer. You should then run for another hour to complete the initial break in. From here many more experienced people will wish to adopt their own preferred break in procedure which is of course fine. From our perspective and from a warranty point of view the minimum requirements are to run the driver as described for at least 2 hours before installation in the final environment. Failure to carry out this process will result in NO WARRANTY support on the speaker. If you have a failure of the speaker you will be asked the warranty question to prove that you have read this manual and adhered to the break in procedure. The answer to the warranty question is "BREAK-IN FOR THE WIN!" Please repeat this phrase if you are asked to answer the warranty question. Later in this manual we may reference specific break in procedures for this particular model. They are recommended to be followed but not as mission critical as this initial period.



Before we move to the design and installation of the subwoofer it is important to understand about woofer power handling. The Indy S models are rated for continuous operation at our quoted numbers. It is, however, the system designer that is responsible for choosing equipment that works in harmony together - speaker, enclosure, amplifier and source unit as well as setup. There are vast differences in the fil power handling of a speaker system depending on these factors, and "raw driver" theoretical power limits are only one factor in that fil number. Heat management is the responsibility of the system designer, therefore, and we will not accept warranty claims for burned coils under any circumstances. A burned coil is always because of either bad setup (distortion) or bad heat management (too much power for too long - choose a higher subsonic filter level, a lower crossover low pass point or allow the hardware to cool down between periods of extreme load.) Lets face it, we all want to run with a 10Hz subsonic in a massive enclosure and do huge numbers easily but that's not possible in every case. You have to set expectations accordingly. A race engine might last 2 hours at the absolute maximum level of performance it is capable of. The same engine running a lower state of tune might last many thousands of miles on the road. That's the same engine in a different situation with different setup. Our speakers are no different than this and the longevity will vary in a similar way depending on how close to their thermal and mechanical limits they are run.



The first consideration is enclosure design. This is a complicated and technical subject. You can use our recommended box design where we quote one, or approach your distributor for

advice. Please do not guess the box size as it is a very important part of your success with the product. For the construction of the enclosure we recommend the use of MDF or Weather Proof Ply Board (WBP) in 18mm thickness as a minimum. Do not construct bass boxes from chip board. Improved performance will result from thicker box material - either 25mm or even limitations of thinner material are common methods for improving box rigidity. Corner bracing is popular and works well, as do internal braces between walls. Don't forget to take account of the volume of any inner bracing when you are optimising the box size. When we are designing boxes we always allow an additional small amount (say 0.25 cubic feet or a few litres) of extra space so that we can tune the box accurately afterwards. You can't add space after but you can fill it with bracing and resin or other objects to reduce it! On the larger subwoofers it is essential to make the baffle (the side of the box where the woofer is affixed) from a double layer of 18mm MDF as a minimum. This reduces box interference greatly and is proven to be a worthwhile exercise. DO NOT use screws to fasten your subwoofer into the box. It works but they strip easily, can come undone and do not offer professional repeatability in respect of service work to the enclosure or speaker. We offer our BFTNUT.1 kit which has ten 60mm long high grade M5 bolts with matching T nuts as an excellent way of retaining your woofer to the enclosure.



When running more than one woofer in a mono configuration we recommend that you share enclosure space and keep the speakers as close together as possible in the baffle. This tends to do the most effective job of allowing the speakers to act as a single piston, moving the optimum amount of air. Do note well that should you decide to operate stereo bass you MUST run the woofers in separate air chambers. Additionally, if you are running a

complex setup of multiple amplifiers driving multiple coils or speakers you MUST meter the amplifiers at various levels to ensure the voltages at the coils are equal. Imbalance in this area will at best cost you SPL and at worst will damage your equipment.



You'll be referring to our data and speaking to our distributors to choose a box design, but some general information is that a larger box will tend to give more low bass but at the expense of some power handling. If you are lucky enough to have a large and powerful amplifier then you will be able to run the subwoofer harder in a more controlled fashion. A less powerful amplifier always carries with it the risk of burning out the speaker due to distortion and the resulting excessive heat soak.



Every subwoofer installation needs a crossover function - the precise settings are a subject of discussion for each particular setup but a good starting point is to work with a 25Hz subsonic (high pass) filter and a 100Hz low pass filter. Whilst these will not produce optimum results in every case they will certainly be enough to get you up and running.



Once the speaker is installed and working it is vitally important to follow a break in procedure. On the Indy S woofers we recommend 20 hours of free air playing with a 20Hz tone as the best possible start. At the start of the break in you should ensure that the speaker is moving to - but not beyond - its maximum excursion. As the parts break in the excursion for a given input will increase and so you need to monitor levels closely so as not to damage the woofer. Of course you must pay close attention to excursion and temperatures of both the woofer and your amplifier. Failure to do this will almost certainly lead to failure of the motor due to the suspension presenting excessive resistance in its pre-break in state. Failure of speakers due to insufficient running in is not covered by warranty. Please note that TS parameters can and do change dramatically after break in - until the speaker is at its equilibrium.

